

Sinfonia

The art of excellent coffeemaking










Sinfonia

Your coffeemachine in an overview

We congratulate you on the purchase of your Franke coffee machine. You have decided for a high quality coffee making machine, developed and manufactered following state of the art technologies. The Franke Kaffeemaschinen AG manufactures its machines according to the ISO 9001 and ISO 14001 standards. Its certification is under permanent control by external agencies.



hot milk

froth









autosteam



Starting up

Installation/starting

-> is carried out by specialists from your supplier. The products and the basic adjustments are programmed following your requirements. You can make changes yourself through the «customer menu» function. [See 8-10].

Machine is plugged in but switched OFF: working condition «Energy-Save-Mode»



Switch on/warming up

cappuccino

macchiato

Water supply open! Beans/milk filled up!









Select product

Heating... Macchiato

coffee







Unit ready to use!



For adjustments see page 8 - 10



Safety...

Ambient temperature

- Distance back panel

- Noise emission (steam service) min. 10°C max. 32°C min. 20mm

>70dB (A)!

Carefully read these instruction's, especially the safety instructions before initial operation. For damages which occur out of non compliance with this instruction, no liability exists. Keep this instruction manual to hand where other user's can readily refer to it!

If the coffee machine is taken out of use or is no longer used, it should be disconnected from the power and water. In any other case local regulations are binding.

Prepare beverages

Coffee and milk products...


... or hot water/steam



- Refill coffee beans (container 1, 2/3)
- Only use fresh and cool milk!
- Clean air nozzles if no frothed milk is made (see page 5. Hint)









Place cups under outlet









Blocked products

-> deletes ALL preselected





Choose product

Menu 1 and 2 are examples.

For adjustments to your needs see page 8/9

Quantities preprogrammed

Hot water

For adjustments to your needs see page 8/9

Steam







If programmed obtain products simultaneouly Do not use instant coffee

The coffee ground must be emptied after every opening of the coffee ground door



STOP

premature

or as programmed

ON



















Double portions

e.g. 2 coffee [if in menu]





possible in menu 1 (= Alt-function) and menu 2! HINT


Double click only possible if programmed!



wipe off until clean!

Safety...

CAUTION! DANGER OF BURNS DANGER OF INJURIES




NEVER put your hand in the bean container during operation!

Do NOT pour liquids on the cup-tray or the bean containers



Caution hot Coffee/Water/Steam keep clear from the dispensing heads





Do not swivel wand upwards when producing steam



OFFEE SYSTEM

Maintain/clean unit


The cleaning procedure of the coffee system needs approx. 5 min./with milk system approx. 7 min.
Use ONLY the cleaning products recommended by Franke (see page 7)!

Rinsing and daily cleaning










Clean AT LEAST once a DAY

or MANUAL

























Your customer service

Auxiliary material, spare parts, service

- Use of FRANKE Original accessories, auxiliary material and spare parts is the best way to assure a long and secure life time of your Franke machine.






specially tested and recommended by Franke





Cleaning brush



ADJUST




Art.-Nbr. 10 300 924



Spare parts / service

For maintenance / repair / spare parts /...

Your competent service partner (company stamp)



Manufacturer

Franke Kaffeemaschinen AG **Dorfbachstrasse 2** CH-4663 Aarburg **Switzerland**

Phone +41-62-787 31 31 Fax +41-62-787 30 10 web www.km.franke.ch e-mail kmch@franke.com



Custom adjustments...

Your customer menu



- You need your Adjust Card for access

- A PIN coded access is programmable -> see menu number 9





Adjust Card





Customer menu

automatically appears with AdjustCard:



HINT



The menus below change depending on product!

...and adjust

...activate

1) Make choice e.g. Prod. Defin. and then e.g. fill quantities 2) Confirm choice




- CLEAN = ENTER button
- · confirm choice with text entry
- «next number»

3) Choose setting(s) -> 4) Choose Exit, Save or Test ->

CLEAN

5) ...and confirm



EXIT Leave menu with EXISTING settings **SAVE** Leave menu with NEW settings

TEST Test setting (filling quantity, grinding quantity, temperature)



Your settings

..customize your Sinfonia

Please pay attention to the indications in the display as they complete this instruction according to the latest version of the operating software of your machine.

Depending on the machine configuration some submenu's may not appear!








PRECAUTION!

During repairs or controls switch off the power supply of the machine!





Code	Message on Display	Measures
1	External RAM	Contact customer service!
2	Missing coffee outlet	Coffee outlet is not installed or not correctly installed.
3	Door open	Close door/Coffee ground container must be emptied, before the door is closed!
4	Frontpanel open	Return panel and lock.
		· ·
10, 11, 14	Temperature sensor	Contact customer service!
15, 18, 19	Temperature sensor	Contact customer service!
12, 16, 20	Temp. difference	Contact customer service!
13, 17, 21	Over temperature	Contact customer service!
22, 23, 24	Heater timeout	Contact customer service!
30, 31	Water supply	Contact customer service!
32	Steam supply	Contact customer service!
40-46	Motor timeout	Contact customer service!
50, 54	Chipcard read	Contact customer service!
51, 52, 53, 55	Chipcard identify	Contact customer service!
57, 58, 59, 60	Chipcard write	Contact customer service!
100	Drawer full	Empty coffee ground container.
110	Flowmeter	Control water tube/contact customer service!
120	Out of beans	Fill up coffee bean funnel and push button again.
130	No Milk	Control milklevel, fill up milk.
140	Communication	Contact customer service!
150	Empty drawer	Empty coffee ground container.
160	Battery low	Contact customer service!

H I N T

Switch machine ON/OFF: if error message still appears -> consult list

Set machine out of order

This TSM SUCCESS MANUAL® has been examined by Electrosuisse for conformity with the safety relevant standards, and has been analysed by an applicationoriented risk analysis for the completeness and correctness of the indications for a safe use of the appliance. Thereby we assume a use with which can be reckoned based on common sense.



