

VERTICALE-VER02 from 2009



BEZZERA


Dal 1901

COD. 9942017.08

REV.00

[illegible]

TABLE 1
Mod. DE - PM - TP - TE



[illegible]

TABLE 1A
Mod. DE - PM - TP - TE






TABLE 2
Mod. DE - PM - TP - TE




rev.00

TABLE 3 (up to 16.02.10)
Mod. PM



rev.00

TABLE 3 (up to 31.08.10)
Mod. PM



rev.00

TABLE 3 (from 01.09.10)
Mod. PM




TABLE 3A (up to 16.02.10) Mod. DE

POS	CODE	DESCRIPTION
1	7496020	OR GASKET 2112 VITON
2	7431001	FLOW METER + AUT. WITH LED
3	5471001	NET FILTER D11 AISI 304
4	5191501	SPACER D11X8X6.5 PTFE
5	5302009	STRAIGHT FITTING M12 X 1/4"G H24 OT
6	5221821	NUT 1/4"G H5 OT
7	5283048	SURPRESSION VALVE BODY
8	5493001	GASKET D8 X 4 EPT 70SH
9	5224615TP	GASKET-HOLDER
10	5471505	CALIBRATED SPRING D0.45 H22 AISI 302
11	5302018	STRAIGHT FITTING M12XM13 ES.16 H26.5 OT
12	5224619	GASKET-HOLDER D5.3 OT
13	5471506.01	CALIBRATED SPRING D1.1 H32 AISI 302
14	7496052	OR GASKET 114
15	5302071	RUBBER-HOLDER FITTING M12x1 OT
16	5194554	SURPRESSION VALVE DRAIN HOSE
17	5999906	WASHER D20 X 30
18	5302014	FITTING M13X1/8"G ES.15 H23.5 OT
19	5965164	ASSEMBLY SURPRESSION VALVE 12BAR
20	7400901	CAPILLARY 1.27X2.51X500 1/8" M12X1
21	7631505	FLOW METER CONNECTOR
22	7816405	SCREW TE M4X12 UNI 5739 A2
23	7200504	INOX FLEXIBLE HOSE 3/8"G L=1500
24	5162261LL	INLET AUTOMATIC LEVEL HOSE DE
25	5038105LW	BRACKET FOR FLOW METER
26	7815003	PLAIN WASHER D5 UNI 6592 A2
27	5162257LL	SURPRESSION VALVE / CONT. VOL. DE
28	7496018	OR GASKET 105 VITON
29	5302501	MULTIPLE FITTING 5 WAY OT (DE)
30	5221823	NUT M20x1.25 ES.26 H5 OT
31	5226405TP	PLUG 1/4"G ES.16 H13 OT
32	5302061	FITTING MF 3/8X1/4 OT
33	5471002	FILTER D13.5 H11 AISI 304
34	7702312	SOLENOID VALVE 2 WAY 220/240V PARKER
34	7701114	SOLENOID VALVE 2 WAY 110V PARKER
35	7630325	SOLENOID VALVE COIL 220/240V PARKER
35	7630324	SOLENOID VALVE COIL 110V PARKER
36	5225238	FITTING M13X1/8"G ES.15 H23.5 OT
37	7703011	SOLENOID VALVE WITHOUT COIL PARKER
38	5471019	FILTER D8.5X5 AISI304
39	7304502LL	FITTING SERTO 1/8"G
40	7496035	OR GASKET D4.2 X 1.9 VITON
41	5224002	STUD D8.5 X 17.5 OT
42	5302015	FITTING 1/8"G OT
43	5223003	JET M6 X 6 HOLE D0.8 OT
44	5223018.01	COMPLETE CHECK VALVE

TABLE 3A (up to 16.02.10)
Mod. DE




TABLE 3A (up to 16.02.10) Mod. DE

[illegible]

TABLE 3A (up to 16.02.10)
Mod. DE





TABLE 3A (up to 31.08.10) Mod. DE	POS	CODE	DESCRIPTION
	1	7431001	FLOW METER + AUT. WITH LED
	2	5471001	NET FILTER D11 AISI 304
	3	5191501	SPACER D11X8X6.5 PTFE
	4	5302009	STRAIGHT FITTING M12 X 1/4"G H24 OT
	5	5221821	NUT 1/4"G H5 OT
	6	5283048	SURPRESSION VALVE BODY
	7	5493001	GASKET D8 X 4 EPT 70SH
	8	5224615TP	GASKET-HOLDER
	9	5471505	CALIBRATED SPRING D0.45 H22 AISI 302
	10	5302018	STRAIGHT FITTING M12XM13 ES.16 H26.5 OT
	11	5224619	GASKET-HOLDER D5.3 OT
	12	5471506.01	CALIBRATED SPRING D1.1 H32 AISI 302
	13	7496052	OR GASKET 114
	14	5302071	RUBBER-HOLDER FITTING M12x1 OT
	15	5194554	SURPRESSION VALVE DRAIN HOSE
	16	5999906	WASHER D20 X 30
	17	5302001	STRAIGHT FITTING 1/4"G X M13 OT
	18	5965164	ASSEMBLY SURPRESSION VALVE 12BAR
	19	7400901	CAPILLARY 1.27X2.51X500 1/8" M12X1
	20	7631505	FLOW METER CONNECTOR
	21	7816405	SCREW TE M4X12 UNI 5739 A2
	22	7200504	INOX FLEXIBLE HOSE 3/8"G L=1500
	23	5162261LL	INLET AUTOMATIC LEVEL HOSE DE
	24	5038105LW	BRACKET FOR FLOW METER
	25	7815003	PLAIN WASHER D5 UNI 6592 A2
	26	5162257LL	SURPRESSION VALVE / CONT. VOL. DE
	27	7496018	OR GASKET 105 VITON
	28	5302501	MULTIPLE FITTING 5 WAY OT (DE)
	29	5221823	NUT M20x1.25 ES.26 H5 OT
	30	5226405TP	PLUG 1/4"G ES.16 H13 OT
	31	5302061	FITTING MF 3/8X1/4 OT
	32	5471002	FILTER D13.5 H11 AISI 304
	33	7702312	SOLENOID VALVE 2 WAY 220/240V PARKER
	34	7701114	SOLENOID VALVE 2 WAY 110V PARKER
	34	7630325	SOLENOID VALVE COIL 220/240V PARKER
	35	7630324	SOLENOID VALVE COIL 110V PARKER
	35	5225238	FITTING M13X1/8"G ES.15 H23.5 OT
	36	7703011	SOLENOID VALVE WITHOUT COIL PARKER
	37	5471019	FILTER D8.5X5 AISI304
	38	5223003	JET M6 X 6 HOLE D0.8 OT
	43	5965076	COMPLETE CHECK VALVE
	44	5162262LL	OUTLET HOSE L/A DE
	45	5283042	CHECK VALVE BODY
	46	5492008	GASKET D10.5 X 2
	47	5221813	PLUG M12X1 OT
	48	7496020	OR GASKET 2112 VITON

TABLE 3A (up to 31.08.10)
Mod. DE



rev.00

TABLE 3A (from 01.09.10)
Mod. DE





TABLE 3B (up to 16.02.10) Mod. TE


[illegible]

TABLE 3B (up to 16.02.10)
Mod. TE




rev.00

TABLE 3B (up to 31.08.10)
Mod. TE




rev.00

TABLE 3B (from 01.09.10)
Mod. TE



[illegible]

TABLE 4
Mod. DE - PM - TP - TE



rev.00

TABLE 5
Mod. DE - PM - TP - TE





TABLE 6 Mod. DE - PM - TP - TE

[illegible]

TABLE 6
Mod. DE - PM - TP - TE



rev.00

TABLE 7
Mod. DE - PM - TP - TE




TABLE 8 Mod. DE - PM - TP - TE

[illegible]

TABLE 8
Mod. DE - PM - TP - TE





TABLE 9 Mod. DE - PM - TP - TE

[illegible]

TABLE 9
Mod. DE - PM - TP - TE



[illegible]

TABLE 10
Mod. DE - PM - TP - TE 10





TABLE 11 Mod. PM - TE

[illegible]

TABLE 11
Mod. PM - TE



This diagram illustrates the exploded view of a mechanical assembly, likely a pump or valve unit. The components are numbered 1 through 11, and specific parts are labeled with codes: TAV.08, TAV.04, TAV.03A, and TAV.03A.


- Part 1:** Two small O-rings or seals.
- Part 2:** A small fitting or connector.
- Part 3:** A long, thin tube or pipe.
- Part 4:** A curved pipe or hose.
- Part 5:** A flexible hose or pipe with a fitting.
- Part 6:** A small fitting or connector.
- Part 7:** A circular flange or base plate with multiple mounting holes.
- Part 8:** A small screw or bolt.
- Part 9:** A small fitting or connector.
- Part 10:** A small nut or washer.
- Part 11:** A long, thin tube or pipe.

The assembly is shown in a disassembled state, with dashed lines indicating the alignment and assembly sequence. The components are arranged around a central circular flange (7). The labels TAV.08, TAV.04, TAV.03A, and TAV.03A point to specific parts or sub-assemblies.

TABLE 12 (up to 31.08.10) Mod. PM - TP

[illegible]

TABLE 12 (up to 31.08.10)
Mod. PM - TP



rev.00

TABLE 12 (from 01.09.10)
Mod. PM - TP




TABLE 12A (up to 31.08.10) Mod. DE - TE

[illegible]

TABLE 12A (up to 31.08.10)
Mod. DE - TE





TABLE 12A (from 01.09.10) Mod. DE - TE


[illegible]

TABLE 12A (from 01.09.10)
Mod. DE - TE




[illegible]

TABLE 13
Mod. TP



[illegible]

TABLE 13A
Mod. PM



rev.00

TABLE 13B (up to 24.05.10)
Mod. DE - TE





TABLE 13B (from 25.05.10) Mod. DE - TE

[illegible]

TABLE 13B (from 25.05.10)
Mod. DE - TE



[illegible]

TABLE 14 (up to 31.03.10)
Mod. DE - PM - TP - TE





TABLE 14 (up to 02.12.12) Mod. DE - PM - TP - TE


[illegible]

TABLE 14 (up to 02.12.12)
Mod. DE - PM - TP - TE



[illegible]

TABLE 14 (from 03.12.12)
Mod. DE - PM - TP - TE



rev.00

TABLE 16
Mod. PM - TP






TABLE 17 (up to 24.05.10)
Mod. DE - TE



rev.00

TABLE 17 (from 25.05.10)
Mod. DE - TE





BEZZERA

Dal 1901

G.BEZZERA

MACCHINE PER CAFFE' ESPRESSO

Via Luigi Bezzera,1

20088 Rosate - Milano - Italy

Tel. ++39 02 90848102 r.a. - Telefax ++39 02 90870287

Web: www.g.bezzera.it

e-mail: commerciale@bezzera.it