BAMBINO 2 GROUP ESPRESSO COFFEE MACHINE

(Parts List)

Fracino Ltd. 17-19 Birch Road East Birmingham B6 7DA

Tel: 0121 328 5757 Fax: 0121 327 3333

email: sales@fracino.co.uk

Contents

Page

3-6	Parts list
8	Bodywork
9	Bodywork (auto version)
10	Chassis
11	Boiler
12	Group
13	Brewing cup
14	Manifold
15	Sight glass
16	Steam and hot water valves


Part No.	Description	Quantity	
	·		
	Body Work		
BAM2CS	Cup shield	1	
BAM231	Cup tray top	1	
BAM242	Left end panel (black)	1	
BAM242S	Left end panel (St. steel)	1	
BAM243	Right end panel (black)	1	
BAM242S	Right end panel (St. steel)	1	
BAM249	Front panel (groups)	1	
BAM240	Rear panel	1	
BAM243	Drip tray inner (cups)	1	
BAM237	Drip tray outer	1	
BAM258	Drip tray bottom band	1	
FC189	Main power switch	1	
FC189	Group switch	2	
FC190/9	Neon illuminator	1	
FC116	Cable grommet	2	
	g. c	_	
	Chassis		
BAM228	Chassis	1	
FC140/A	Waste cup valve	1	
BAM222AA	Steam assembly (complete)	1	
BAM222AB	Hot water assembly (complete)	1	
FC224	Rubber feet	4	
FC14012	Expansion valve to waste cup	1	
FC178D	Expansion valve outlet fitting	1	
FC178C	Manifold nut	1	
FC179	Pressure gauge	1	
FC179A	Pressure gauge bracket	1	
BAM152	Pressure gauge to boiler	1	
FC179B	1/8" Lock nut	2	
BAM153	Pressure gauge to manifold pipe	1	
FC224	Pump motor	1	
FC225	Pump head (inc. retaining clip)	1	
FC226	Anti vibration feet	4	
FC137	Inlet hose	1	
FC169	Pressure switch lock	1	
FC169A	Pressure switch nut	1	
FC172A	Boiler controller	1	
FC187	Sight glass assembly (complete)	1	
FC157/2.5	Cable restraining bush	1	


Part No.	Description	Quantity	
	·		
	Boiler		
BAM84	Boiler/Safety	1	
FC134	Valve	1	
FC191	Probe	1	
FC162/C	Element 2850W	1	
BAM149	Steam valve to boiler	1	
BAM147	Heat exchange to group (top)	2	
BAM151	Pressure switch to boiler	1	
BAM150	Hot water valve to boiler	1	
FC148	Heat exchange to group (bottom)	2	
BAM141/2	Manifold to heat exchange pipe	1	
FC146/2A	Manual fill/solenoid valve to boiler pipe	1	
LG145	Sight glass to boiler	2	
FC165	Element to gasket	1 1	
. 0.00		'	
	Manifold		
FC138A	Manifold forged	1	
FC170	Manual fill valve	1	
FC178G	Adjustment screw	1	
FC178B	Expansion valve spring	1	
FC178FV2	Expansion valve jumper	1	
FC171	Inlet solenoid valve	1	
FC137	Braded inlet hose	1	
FC180CN	M20 Locknut	1	
FC198	Pad Washer	1	
FC178C	'O' Ring. Silicon	1	
FC178/D	3/8 x 14 special fitting	1	
FC180ANT	Non return valve fitting	1	
FC180BNT	Non return valve stem	1	
FC180DNT	Non return valve spring	1	
I CTOUDINT	Non retain valve spring	1	
	Auto Version		
FC92	Flow meter	2	
BAM154/2	Manifold to flow meter pipe	1	
BAM155	Flow meter to heat exchange pipe	2	
DAMITOO	Flow meter to near exchange pipe	2	
			_


Part No.	Description	Quantity	
	•		
	Filter Holder		
FC107	Single filter (7grm)	1	
FC107/D (10)	Single filter (10 grm)	1	
FC107 POD	Single pod filter	1	
FC110	Filter spring	2	
FC111A	Single beak	1	
FC105	Single filter holder complete	1	
FC108 (12)	Double filter (12grm)	1	
FC108/D (14)	Double filter (14grm)	1	
FC108 POD	Double pod filter	1	
FC105A	Double filter holder complete	1	
FC112	Double beak (closed)	1	
FC112/I	Double beak (open)	1	
FC112/AF	Double beak adjustable flow	1	
FC111A	Single beak curved	1	
1011171	Olingio Boak ourvoa	'	
	Group		
FC132B	Blank nut small	1	
FC99	Group body	1	
FC104	Filter holder washer (8.0mm tck)	1	
FC104/85	Filter holder washer (8.5mm tck)	1	
FC104/9	Filter holder washer (9.0mm tck)	1	
FC104P	Filter holder paper packing	1	
FC104B	Filter holder washer locking plate	1	
FC103M	Shower plate	1	
FC103S	Shower plate screw	1	
FC97B	Group cowl	1	
FC132A	Top jet filter holder	1	
FC130	Filter	1	
FC129A	Jet	1	
FC101	Group gasket	1	
FC120	Solenoid base 'O' ring	2	
FC116	Solenoid base	1	
FC119	Solenoid base screws	4	
FC121	Solenoid nucleus body	1	
FC121/V	Solenoid nucleus viton	1	
FC122	Solenoid outer case	1	
FC124/1	Solenoid coil (sealed)	1	
FC124A	Coil washer	1	
FC124B	Coil spring washer	1	
FC1214C	Coil lock nut	1	
FC95N	Exhaust fitting	1	
. 55514		1	


Part No.	Description	Quantity	
	·		
	Sight Glass Assembly		
VES181	Sight glass	1	
FC182	Sight glass 'o' ring viton	2	
FC183	Sight glass brass ring	2	
FC184	Sight glass top holder	1	
FC182	'O' ring (sight glass top holder)	1	
FC185	Sight glass bottom holder (including drain plug	1	
FC185A	Sight glass holder	-	
FC185B	Sight glass drain plug (chrome)	-	
FC186	Sight glass retaining nut	2	
LG191	Probe (working level)	1	
LG191A	Probe St. steel rod	-	
FC191B	Probe insulator	-	
FC196B	3/8" BSP Lock nut	2	
FC196C	3/8" BSP St. steel washer	2	
LG190G	Neon green water fill	1	
	Water and Steam Wand Valves		
BAM222AB	Hot water valve and tube assembly (complete)	1	
BAM222AA	Steam valve and tube assembly	1	
	(complete)		
ROM222M	Cap for hand wheel (hot water) chrome	1	
ROM222L	Cap for hand wheel (steam) chrome	1	
FC222K/D91	'R' Holding clip St. steel	2	
FC222J	St. steel securing washer	2	
FC222H/R	Hand wheel curved sided (black)		
ROM222H	Hand wheel curved sided glitter	2	
FC222N	Hand wheel tension spring	2	
FC222P	Spring retaining cup	2	
FC222Q	Hand wheel spacer	2	
FC196B	Lock nut 1/2" BSP	2	
FC222R	Valve head and steam guide	2	
FC222S	'O' Rings valve stems	4	
FC222T	Brass gland stem seal	2	
FC222U	Spring (valve stem)	2	
FC222V	Valve stem with jumper	2	
FC198A	Pad washer	2	
FC222A	Valve body	2	
FC222G	Seal	2	
FC222C	Spring (steam pipe)	2	
FC222F/M	Brass spacer spherical 'end mod'	2	
FC222E/M	'O' ring spherical 'end mod'	2	
FC221D	Steam/water tube retaining nut	2	
BAM2221ES	Water pipe St. steel	1	


BAM222X/SS	Steam pipe St. steel	1	
FC194/D	Non-splash hot water nozzle	1	
FC194/B	Steam jet nozzles standard	1	
FC56	Safety clip for steam/water pipe	2	
	Miscellaneous		
FC158	Power cable (integral plug)	1	
FC159/2GR	Harness wiring (auto)	1	
FC160/2GR	Harness wiring (semi)	1	


















BAMBINO (2 GROUP ESPRESSO COFFEE MACHINE) FC182 FC191 -LG191A -LG191B FC196B -FC196C FC184 -FC182 FC183 -LG190/G FC186 FC183 FC182 FC181--FC196B -FC196C -FC185A--FC185 -FC185B-SIGHT GLASS © FRACINO 2004 Page 15



Circuit diagram two group MC's fitted with FC91/2/NT (ET30) Optional timed Touch pad FC94C (Including short scart lead) FC190 TP1 TP2 Flow Inlet meters FC171 CN2 TEA R5 FM2 OUT 2 EVL OUT 1 Low level SM SM FM1 EV2 **CONTROL BOXES** EV1 R2 11 PMP R1 2 Group ET30 Groups COM FC191 NEUTRAL 1G -LIVE 10 (If fitted) Pump Pressure motor switch Ν FC189 E High power FC174A FC169 Elements version only No relay © FRACINO 2004